

How to quickly fix a broken Center Line

The Center Line on a kiteboarding bar is kind of like a car's brake pads; it eventually wears out and has to be changed. This doc is to explain how to quickly fix a StarKites' NeX Bar's center line if no spare replacement parts are available in your vicinity.

- 1) Use an Allen key to unscrew the head of the Chicken Loop.



- 2) Take apart the head.



- 3) Obtain a 2 meters of rope approximately 5 or 6 mm in Diameter.



4) Insert the line through the two holes of top plastic piece of the chicken loop.



5) Re-assemble the head of the chicken loop.



6) Pass the two line ends bar bottom first.



7) Make a simple knot with the two lines, make it tight at the distance you'd like (the default distance is 45cm).



8) Put one of the line ends through the bottom eye of the depower strap. All the way to the knot.



9) Make an Eight knot with the two line ends, tighten it as close to the simple knot as possible. Cut off the excess line and burn the ends to prevent fraying.

Go to: http://www.ehow.com/how_7534_tie-figure-eight.html to learn how to do a figure eight knot.



You are now ready to go ride!!

